

Fortøyingskart Skår

Vedlegg 6.1.3 c)

Rammefortøyning		
Ankerline	Posisjon	
101	59° 54.197 N	05° 31.913 Ø
102	59° 54.102 N	05° 32.046 Ø
103	59° 54.064 N	05° 32.105 Ø
104	59° 54.024 N	05° 32.144 Ø
105	59° 53.981 N	05° 32.156 Ø
106	59° 53.933 N	05° 32.121 Ø
107	59° 53.887 N	05° 32.109 Ø
108	59° 53.843 N	05° 32.104 Ø
109	59° 53.677 N	05° 32.173 Ø
110	59° 53.654 N	05° 32.158 Ø
111	59° 53.645 N	05° 32.087 Ø
112	59° 53.548 N	05° 32.056 Ø
113	59° 53.769 N	05° 31.456 Ø
114	59° 53.811 N	05° 31.436 Ø
115	59° 53.853 N	05° 31.419 Ø
116	59° 53.896 N	05° 31.400 Ø
117	59° 53.937 N	05° 31.380 Ø
118	59° 53.980 N	05° 31.361 Ø
119	59° 54.021 N	05° 31.342 Ø
120	59° 54.354 N	05° 31.732 Ø
121	59° 54.345 N	05° 31.759 Ø
122	59° 54.217 N	05° 31.886 Ø

Rammehjørne		
NV	59° 54.080 N	05° 31.866 Ø
NØ	59° 54.089 N	05° 31.949 Ø
SØ	59° 53.838 N	05° 32.063 Ø
SV	59° 53.829 N	05° 31.979 Ø
Midtpunkt		
	59° 53.961 N	05° 31.967 Ø

Flåteposisjon		
	59° 53.993 N	05° 32.068 Ø
Flåtefortøyning		
Ankerline	Posisjon	
F101	59° 54.067 N	05° 32.110 Ø
F102	59° 54.038 N	05° 32.175 Ø
F103	59° 53.983 N	05° 32.177 Ø
F104	59° 53.956 N	05° 32.158 Ø
F105	59° 53.917 N	05° 32.022 Ø
F106	59° 53.951 N	05° 31.927 Ø
F107	59° 54.007 N	05° 31.904 Ø
F108	59° 54.070 N	05° 31.930 Ø

